

seal-rite FINISHING system


Finish Removal & Maintenance Instructions for Fiberglass

To file a warranty claim, please contact the authorized dealer where the product was originally purchased.

STRIPPING TO REFINISH

1. Choose a standard paint stripper. Paint or stain and topcoat can be removed with most methylene chloride-based strippers, such as:

- Bix Quick Stripper™
- Savogran SuperStrip™
- Dad's Easy Stripper™
- Bix Tuff Job™
- Kutzit™
- 3M™ Safest Stripper™



2. Apply stripper to doorlite frames first and raised panel inserts second (see illustration). Remove stripper within 2-3 minutes. These components have a factory-applied primer, which may be removed with long exposure to paint strippers. Follow the paint stripper manufacturer's directions and cautions for use of the paint stripper.

Use a brass wire brush, nylon bristle brush or grade 000 steel wool for easier removal of paint and stain from the wood-grain texture.

3. Apply stripper to the rest of the door. Work on small areas at a time. Follow the paint stripper manufacturer's directions and cautions for correct use of the paint stripper.
4. Wash off remaining stripper. After the stain or paint has been removed, scrub the door with an all-purpose cleaner to completely remove any stripper residue. Rinse well and wipe dry.

Make sure door is completely clean and dry before refinishing.

LONG-TERM MAINTENANCE

- To check for loss of gloss or roughness of your door's topcoat over time, use a color test sample and compare it, periodically, to your door. Store any extra stain in a cool, dry place away from the sun.
- Finishes, whether paint or stain can be affected by the varying degrees of exposures to the weather and elements; therefore, finishes should not be viewed as "maintenance free." To maintain the look and performance of your finish, you must maintain the finish regularly.
- A fresh layer of exterior high quality polyurethane should be applied whenever you detect a change in your original finish. Periodic maintenance to the topcoat or paint is required to keep your original pre-finished door system performing well. Clean with a mild detergent.

NOTE: Please follow the manufacturer's instructions when preparing and applying any high quality polyurethane.

- ❌ DO NOT reuse topcoat more than 3 years old.
- ❌ DO NOT use any topcoat that has been frozen.